

#### POWER DEFINITION

PRP: Prime Power is required for continuous operation under variable load and infinite operating hours per year.

ESP: Standby power refers to the ability of the generator to operate at varying loads in the event of power outage, with an annual operating time of up to 200h.

#### STANDARD USAGE CONDITIONS:

- 1. Altitude: below 1000 meters;
- 2. Environmental temperature: 25 °C
- 3. Relative humidity: 30%

#### ABOUT NOISE:

The noise level of the generator largely depends on the installation conditions and usage environment, so it is not possible to specify the noise value in manual. The noise value we provide is based on laboratory testing and is for reference.

#### QUALIFICATION STANDARD

IGNT POWER generator set complies with ISO and CE standards, which also include the following certification standards: ISO 1400:2015 Environmental System; ISO 45001:2018 Safty System; ISO 9001:2015 Quality System

SERVICE		PRP	ESP
Power	KVA	125	138
Power	KW	100	110
Standard Voltage	V	400/230	
Available Voltage	V	380/220	415/240
Rated Current	А	180	
Frequency/Speed	HZ/RPM	50/	1500

### Weight and Dimension

	Dimensior	1	0pen	Silent
Length	(L <b>)</b>	mm	2400	3290
Width	(W)	mm	950	1130
Height	(H)	mm	1510	1850
Net Weight	t	KG		
Fuel Tank		L		400

# IG138WP

### INDUSTRIAL RANGE POWER <u>BY WEICHAI</u>



## Engine Specifications

General Engine Date	WEICHAI
Engine Model WI	P6D132E200
Governer	E
Aspiration Turbocharged &	aftercooled
No. of Cylinders	6
Displacement (L)	6.75
Bore* Stroke (mm)	105*130
Compression Ratio	18:01
Rated Net Power(KW)	120
Fuel system mech	hanical pump

Fuel System		
Fuel Consumption @100% ESP	L/h	/
Fuel Consumption @100% PRP	L/h	23.8
Fuel Consumption @75% PRP	L/h	/
Fuel Consumption @50% PRP	L/h	/
Fuel Tank Capacity	L	360
Fuel Tank Capacity (Silent)	L	/
Starter System		
Start Motor Voltage	V	24
No. of Batteries		2

Aspiration syste	m		Coo
Clean filter	kPa	≪3.5	Total
Dirty filter	kPa	/	Thermo
Air flow	m3/min	544	Max wa
			-

Cooling System		
Total coolant capacity	L	8
Thermostat operation range	°C	76-90
Max water temperature	°C	101

Lubrication Syste	em		Exhaust system		
Oil capacity	L	20	Max.exhaust temperature	°C	550
0il consumption	g/kwh	0.2	Exhaust gas flow	L/s	567.8
0il pressure	kPa	300-600	Max.allowed back pressure	kPa	6.5

## Alternator Specifications

Alternator Date IGNT		Alternator Date	- Stamfor	ď
Alternator Model	IA274D	Alternator Model		UCI274D
Phase	3	Phase		3
Voltage (V)	400	Voltage	V	400
Prime Power (KW)	100	Prime Power	KW	100
Pole	4	Pole		4
Excitation System 1f-excited	, Brushless	Excitation System		elf-excited, Brushles
No. of Bearing	1	No. of Bearing		3
Power Factor	0.8	Power Factor		0.8
Wiring Connection 3 Phases	, 4 Wires	Wiring Connection		3 Phases, 4 Wires
Insulation Grade	H/H	Insulation Grade		H/H
Protection Grade	IP23	Protection Grade		IP23
Voltage Regulation (%)	$\pm 0.5$	Voltage Regulation	%	$\pm 0.5$

# IG138WP

### INDUSTRIAL RANGE POWER BY WEICHAI



### Controller Specifications

Control Panel Date Deepsea DSE6120	
<ul> <li>Built in PLC logic programming</li> </ul>	• Generator/load current monitoring and protection
Generator voltage detection	Fuel pump control function
Mains voltage detection	<ul> <li>Can connect to all expansion modules</li> </ul>
● Generator/load power detection (kW, kVA, kVAr, pf)	Capable of graded loading
ullet Generator overload protection (kW)	<ul> <li>Engine speed protection</li> </ul>
E site of its manual state on the second constraints	En stars constructions

- Equipped with manual closing and opening functions 🛛 🗨 Engine preheating
- Start gen-set when the battery voltage is low
- LCD and LED alarm indication

- Engine starts rapidly&stops rapidly

### Generator Specifications

Standard Configuration	Optional Configuration
● 50°C radiator for belt driven fan	<ul> <li>Battery charger</li> </ul>
● 12/24V charging alternator	● Engine pre-heater
One set of air/fuel/oil fiters	Alternator pre-heater
<ul> <li>Chassis with integrated fuel tank</li> </ul>	● PMG/ AREP/ MAUX
• Emergency stop button	<ul> <li>Water-oil seperator</li> </ul>
ullet Anti-vibration shock absorbers	ullet Inside automatic transfer switch/ ATS box
<ul> <li>Main circuit breaker/ MCCB</li> </ul>	Grounding cooper rod
● Auto control system	Remote control system
● User manual	• Switch box

### Warranty of Generator Set

Generator

One year or 1000 running hours whichever comes first

Email: ignt@igntpower.com Web: www.igntpower.com